□ REAL-EL

USER'S MANUAL



RS-Protect

RS-Protect

Congratulations on purchasing the TM REAL-EL surge protector!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

© 2015. ENEL GROUP OU.

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

PACKAGE CONTENTS

- Surge protector 1 pc
- Warranty card/User's manual 1 pc

APPLICATION

The **RS-Protect** surge protector is designed for connection of electrical appliances to the electrical network and their protection from an pulse overvoltage.

R5-Protect

FEATURES

- Power switch with built-in fuse and backlight
- Grounded sockets
- Resettable fuse does not require replacement
- Non-flammable high-impact case
- Pure copper cable without alloys

SAFETY PRECAUTIONS

- Do not connect the surge protector to the electrical network with overrating voltage.
- Do not connect the load to the surge protector with the total power, which exceeds the power indicated in specifications of this device.
- Do not use the surge protector in places with possible ingress of liquid, moisture, dust and high temperature exposure.
- Do not open and do not make any repairs by yourself.
- Connect the surge protector to the grounded electrical network.

CONNECTION

- Connect equipment to surge protector sockets.
- Connect the surge protector to 230 V electrical network, turn on the master switch.

OPERATION

- Do not overload the surge protector by connection of several powerful devices.
- On operation of the automatic fuse due to the overload, turn on the surge protector once more in 5-10 minutes after reduction of the total connected load to a permissible limit. For this purpose, turn the power switch.
- If high-voltage impulses or intolerable high voltage occurs at the surge protector input, the built-in emergency protection can disconnect the surge protector completely. The surge protector operation with the partial or complete resource loss of the surge protector components is intolerable.

R5-Protect

TECHNICAL SPECIFICATIONS

Parameters and measurement unit	Value
Rated input voltage, V	~230
Operating frequency, Hz	50
Total power of connected load, kW	≤ 2.3
Maximum energy absorption of pulse interference, J	350
Maximum load current, A	10
Input plug type	CEE 7/7
Output socket type	5 × CEE 7/3
Cable length, m	1.8/3/5/10
Dimensions (L × H × W), mm	280 × 45 × 50

Notes:

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.
- Technical specifications and package contents are subject to change without notice due to improvement of TM REAL-EL production.



Model: RS-Protect

 $\label{eq:manufacturer:energy} \textbf{Manufacturer: ENEL GROUP OU}, \textbf{Katusepapi tn 6, Lasnam\"ae district, Tallinn city,}$

Harju county, 11412, Estonia. Made in China.

® Registered Trademark of ENEL GROUP OU. Estonia.