II REAL-EL

USER'S MANUAL



WIRELESS STANDARD KEYBOARD + MOUSE Kit

555 Kit WIRELESS

STANDARD

User's Manual

STANDARD 555 Kit Wireless

Congratulations on purchasing the TM REAL-EL keyboard + mouse wireless kit!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

 \circledast 2015. ENEL GROUP OU. This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

UNPACKING

Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.

SPECIAL FEATURES

- · Ergonomic design of the keyboard and mouse
- · Battery long service life
- Coverage range up to 10 m
- Automatic connection, no need to match the receiver with the keyboard
- High-quality keyboard membrane
- USB Interface
- Quiet and precise keystroke
- 1000 dpi mouse resolution

PACKAGE CONTENTS

- Wireless keyboard 1 pc
- Wireless mouse 1 pc
- 2.4 GHz USB nano receiver 1 pc
- 1.5V DC AAA batteries 3 pcs
- User's Manual 1 pc
- Warranty card 1 pc

SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8.
- Free USB port.

Wireless Standard Keyboard +Mouse Kit

STANDARD 555 Kit Wireless

INSTALLATION


• Open the cover of the mouse battery compartment, insert two 1.5V DC AAA batteries into the battery compartment matching the polarity, and close the cover of the battery compartment (see Fig. 1).

• Open the cover of the battery compartment at the keyboard, insert 1.5V DC AAA battery matching the polarity, and close the cover of the battery compartment (see Fig. 3).



Please match the polarity when installing the batteries. Incorrect polarity can cause malfunction of the device, which gives no claims for warranty servicing.

It is necessary to always install only the same type of batteries, because installation of different types of batteries with different levels of charging can cause leaking of one of the batteries, which can damage the device.



Technical support: www.real-el.com

bw⊡

AAA

Fig. 3

+

Keyboard battery

1.5V DC, battery: 1 × AAA 1.5V

compartment

CONNECTION

• Connect the 2.4 GHz USB nano receiver (Fig. 2) to a free USB port of your PC.

• Turn your PC. To activate the set, press any button of the mouse or turn the scroll wheel. If the connection is correct, the set will turn on automatically.

• After finishing your work, you can pull out the receiver from the PC USB port and insert it into the mouse as shown in Fig. 4.

• If the mouse or keyboard don't work, connect them to the nano receiver again. To reconnect the mouse to the nano receiver, press its right button and the scroll wheel at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port. To reconnect the keyboard to the nano receiver, press its «Esc» и «K» buttons at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port. **Notes:**

• Do not place the receiver into a confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.

• If batteries run down, there are «lapses» in operation of the mouse or keyboard. In such a case replace the batteries with new ones.

• If there is a long pause in operation of the mouse or keyboard, they enter the Sleep mode. To enter the working mode just press any button.

TROUBLESHOOTIN	IG
----------------	----

Problem	Solution
The keyboard and mouse are not working.	 Check whether the batteries have been installed correctly. If necessary, replace the batteries with new ones matching the polarity. Pull out the USB nano receiver and insert it back, make sure that it is not damaged. Reprogram the USB nano receiver using the software you can download at www.real-el.com We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.



Wireless Standard Keyboard +Mouse Kit

STANDARD 555 Kit Wireless

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	104
Q-ty of mouse buttons	2 + 1 (scroll wheel)
Keyboard layout	Rus/Ukr/Eng
OS compatibility	Windows XP/Vista/7/8
Interface	USB
Extrapolated mean life (keyboard)	more than 20,000,000 strokes
Extrapolated mean life (mouse)	more than 3,000,000 strokes
Mouse resolution, dpi	1000
Battery type (keyboard)	1 × AAA 1.5V DC
Battery type (mouse)	2 × AAA 1.5V DC
Keyboard dimensions ($W \times H \times L$), mm	438.5 × 136 × 16.6
Mouse dimensions ($W \times H \times L$), mm	115 × 60 × 37
Weight (keyboard + mouse), g	335 and 55

Notes:

• Technical specifications given in this table are supplemental information and can not give occasion to claims.

• Technical specifications and package contents are subject to change without notice due to improvement of TM REAL-EL production.



Model: Standard 555 Kit Wireless

Manufacturer: ENEL GROUP OU, Joe tn 5-39, Tallinn, Harjumaa 10151, Estonia. Made in China.

® Registered Trademark of ENEL GROUP OU. Estonia.